

Factory Process & Equipment Noise

**Engineering Controls** 

## John Sofra, BSME, MBA

- Mover 32 years of experience in engineering, marketing, and sales of acoustic systems and products.
- MCurrently the North America Markets & Sales Manager for the Airflow Attenuation, Industrial, and Environmental markets, Kinetics Noise Control, Inc.
- Mactively involved in AMCA, Air Movement Control Association and ASHRAE, American Society of Heating, Refrigeration, Air Conditioning Engineers



### Factory Process & Equipment Noise – Engineered Controls <u>Purpose and Learning Objectives</u>

MThe purpose of this presentation is to discuss the effects of noise on human hearing, cost of hearing conservation programs and successful methods of noise control

MAt the end of this presentation, you will be able to:

- 1. Identify the 8-hour time weighted average noise level set by OSHA that requires the implementation of a hearing conservation program
- 2. Identify the three main characteristics of effective noise control
- 3. Describe the advantages of implementing engineering controls in lieu of personal protective equipment
- 4. Identify different products used for controlling noise in a factory setting

## Which are you most likely to say?

M"Wow, that is a nice sound!"

M"Wow, that is a nice noise!"

### Noise & Sound

#### MNoise is unwanted sound

MSound is a propagating disturbance (a wave) in a fluid or solid

MIn a solid (structure-borne sound), this disturbance travels as bending, compressional, torsional, or shear waves (vibration)

MIn a fluid (airborne sound), this disturbance travels as a longitudinal compression wave (this is what your ears sense, a fluctuation in sound pressure)





## When is Noise Control Required?

MOSHA's Noise Standard (29 CFR 1910.95) requires employers to have a hearing conservation program in place if workers are exposed to a time-weighted average (TWA) noise level of 85 decibels (dBA) or higher over an 8-hour work shift

Level (dBA)	Comment	
65	normal conversation	
90-95	hearing loss from sustained exposure	
125	start to experience pain	
140	quickly causes irreversible hearing damage	

# Overall Sound Level (dBA)


MNoise sources – levels for comparison

OSHA "Action Level" 8 hrs. Exposure	85 dBA, TWA
Common Sound	Noise Level
Pneumatic Chipper	115 dBA
Generators	105 dBA
Vacuum Pumps	105 dBA
Hammer Mills	102 dBA
Exhaust Fans	101 dBA
Air Compressors	99 dBA
Chop Saw	98 dBA
Metal Recycling	95 dBA
Forklift Traffic	87 dBA
Corn field, Middle of Nowhere at 4:00 am	25 dBA

# Noisiest Manufacturing Industries


#### MPersonnel exposed to noise levels above 90 dBA:

- M Lumber & Wood
- M Textiles
- M Petroleum & Coal
- M Utilities
- M Chemicals
- M Printing & Publishing
- M Fabricated Metals
- M Food
- M Furniture & Fixtures
- M Rubber & Plastics
- M Stone, Clay, & Glass
- M Etc.



### Rule of Thumb

MWhen you feel the need to raise your voice in order to be heard 3 feet away, the noise levels are probably 85 dBA or more and "action" is required



## Types of Controls

MEngineering – eliminate or engineer out the noise by using noise control products or replacing loud, older equipment with new, quieter equipment



MAdministrative – incorporate changes in work procedures such as reducing the duration & frequency personnel are exposed to high noise levels

MPPE - personal protective equipment




## Foam Ear Plugs - PPE

- MPeriodically removing ear plugs to use a radio or make a phone call exposes your ears to high noise and productivity suffers
- MSome people find foam earplugs <u>uncomfortable</u> no matter standard or custom fit
  - MFoam earplugs can wiggle loose, requiring work stops to refit them
- MDo not have listen-through technology

  MThey block important noises including traffic, alarms, warning shouts
- MEar <u>health risk</u> bacteria love foam resulting in ear infections or tinnitus (constant ringing in the ears)

## The True Story

MEarplugs and muffs – noise reduction rating (NRR)



# Costs – Hearing Conservation Program

MHearing conservation programs (HCPs) mandated by the US Occupational Safety and Health Administration (OSHA) can cost an employer about \$350/worker/year as reported by OSHA

No. of Factory Employees	Total Estimated Cost  Per Year
10	\$3,500
30	\$10,500
50	\$17,500
100	\$35,000
250	\$87,500
500	\$175,000

Dobie RA. Cost-Effective Hearing Conservation: Regulatory and Research Priorities. Ear Hear. 2018 Jul/Aug;39(4):621-630. doi: 10.1097/AUD.00000000000523. PMID: 29251690.

## #1 Noise Control Myth

MEngineering controls are expensive


MCompared to what?

MPaying disability claims for noise induced hearing loss and Tinnitus?

MPaying for the elements of an effective hearing conservation program?

MReduced safety risk?

MReduced situational awareness?





# ROI – Using Engineering Controls


MStudies show a 10:1 ROI on dollars spent on engineering controls compared to paying disability claims

MMany engineering control projects exhibit an ROI of 2-4 years versus hearing conservation costs which continue year over year, over year, over year...



A Roadmap for Future Noise Control in Acquisition: Acoustical Engineering Controls and Estimated Return on Investment for DOD Selected High Noise Sources, Raymond Fischer, Noise Control Engineering, Inc., Kurt Yankaskas, Office of Naval Research, Code 34, 31st International System Safety Conference, Aug. 11-16, 2013, Boston MA

## Learning the ABC's of Acoustics



## Sound Absorption

MIT it is not possible to reduce noise at its source or block its path, then sound absorption in the space should be considered

MNoise reduction targets of 10 dBA or less are suitably obtained using sound absorption techniques (10 dBA reduction is perceived as sounding half as loud and significant)

MWalls and ceiling of the space become the focus


### MKey factors:

MConstruction of walls, ceiling, and floorMLength, width, and height of the spaceMLighting, sprinklers, and other obstructions

## Sound Absorption

MA material takes in sound energy as opposed to reflecting the energy

MPart of the absorbed energy is transformed into heat and part is transmitted through the absorbing body



### Quilted Absorber

MIssue – reverberant (echo) industrial facilities:

MAutomotive garages

MEnvironmental control booths

Material handling wrap

Machine housing

MThe <u>thicker</u> the material the <u>better</u> the sound absorption



## Quilted Absorber

MHigh bay area – very congested processes





## Hanging Baffle

MReverberant (echo) industrial facilities:

**MWarehouses** 

MConveyor facilities

Mail handling facilities

MPrinting facilities


MVarious facing materials standard and FDA approved



# Hanging Baffles

MCandy factory, congested process, FDA approved facing

required



## Sound Absorption Panel


MReverberant (echo) industrial facilities:

**MWarehouses** 

MConveyor facilities


Mail handling facilities

MPrinting facilities



## Sound Absorption Panel

MShipping and receiving – forklift traffic & pump room





## Rigid Panel Absorber

MReverberant (echo) industrial facilities:


MWastewater Treatment Plants

MIndoor or outdoor equipment yards

MShipping containers used for generator enclosures


Manywhere where high durability is required





## Rigid Panel Absorber

MProcess manufacturing & test cell applications





## Sound Blocking

MSignificant amount of noise can be reduced by blocking the path of the noise source

MNoise reduction targets range from 18 dBA – 45 dBA

MTreating noise at the source becomes the focus


#### MKey factors:

MProper ventilation of heat radiating equipment MAccess for routine and catastrophic maintenance MVisual access (i.e., ports, process, personnel, etc.)

## Sound Blocking

MSome sound energy is reflected while some is blocked

MThe magnitude of sound energy blocked is in direct relation to the mass of the material (lb./ft2)




### Flexible Barrier

MAbove drop ceilings of break rooms, facility manager's office

MPart chutes

Material handling duct

MProcess piping



## Flexible Barrier

MUnder conveyor – distribution warehouse





## Sound Absorption & Blocking

MOften referred to as a sound absorption and blocking composite

MSignificant amount of noise can be reduced by combining sound absorption and sound blocking

MNoise reduction targets range from 18 dBA – 45 dBA

MTreating noise at the source becomes the focus

#### MKey factors:


MProper ventilation of heat radiating equipment MAccess for routine and catastrophic maintenance MVisual access (i.e., ports, process, personnel, etc.)

# Sound Absorption & Blocking

MSound absorbing material takes in sound energy as opposed to reflecting it

MPart of the absorbed energy is transformed into heat and part is transmitted through the absorbing body

MA portion of the remaining sound energy is blocked by the solid mass material




MBoth absorbs and blocks sound

MFiberglass media

MAluminum, vinyl impregnated, fiberglass facing

M1.0 psf. / 2.0 psf. mass-loaded vinyl



MCustom system – crosscut saw, aluminum extrusions

MEngineering controls can be simplistic MHigh frequency intense whining noise MOnly the operator requires PPE



MCustom system − cutting process



MCustom system – aluminum de-bridging process

MCustom designed to fit the process

MHigh frequency intense whining noise

M100 dBA reduced to 85 dBA





MCustom system – radiator fin press application





MCustom system – wire braiding process

M15 dBA reduction in mid frequency range

MEasy access, process viewing

MNo interference with overhead sprinklers





MSIIding doorway & strip curtains

MIncorporates clear-view ports at proper elevation

Mused to retrofit separation between high noise process area and shipping & receiving area






MRetrofit mechanical room – compressors & fan

MRetrofit mechanical room corner of facility

MControls radiated noise from process centrifugal fan and compressors


MEasy installation




MManufacturing process – plywood tongue & groove



MManufacturing process – office space






MPortable screens

MCan be used in multiple locations for intermittent equipment and process operations



MBoth absorbs and blocks sound
MFiberglass / mineral wool media
MGalvanized, stainless steel,
aluminum sheet construction
MAvailable in various thicknesses for
increased noise reduction
performance



MCustom system − stamping press




MCustom system - CNC machining process



MTest cell – media filter manufacturing



MCustom system – highly accessible, mezzanine elevated process



MProcess fan enclosure – petrochemical facility



MTest cells – automotive manufacturing





#### Ventilation Silencing

- MFans used to move processes (i.e. dust collection, particulate conveying) or cool equipment and personnel all make noise
- MNoise is generated by the fan blades imparting upon air molecules or bad flow conditions
- MQuieter fan models and type can be considered as a possible solution
- MSilencers & acoustic louvers can be tuned to balance pressure loss and noise reduction are a great method of solving noise issues
- MKey factors:
  - Mairflow rate (cfm)
  - M Available fan/system static pressure (energy)

#### Ventilation Silencing – Types


MSilencers come in many shapes, sizes, and performance MFixed-blade acoustic louvers, many models, many thicknesses








#### MWhat makes it tick?





MGeneral building exhaust





Mndustrial process centrifugal fan intake & discharge



MProcess fan exhaust



MDust collection process fan exhaust



#### Fixed Blade Acoustic Louver

MPump house – general ventilation





# KINETICS Noise Control®

Questions?

#### We Create Quiet that Improves the Quality of Life

John Sofra

Markets & Sales Manager – Commercial Airflow, Industrial, Environmental

<u>isofra@kineticsnoise.com</u>